Adjustment

Hoop sensor adjustment

- 1. Attach the hoop stay assembly to the feed unit.
- 2. Enter the test mode, and press [MAIN BOARD TEST MODE] and then [A/D TEST].

- 3. After the hoop stay assembly's LL-hoop has been attached, press [LL] to save the A/D value.
- 4. Replace the LL-hoop with the S-hoop, and then press [S] to save the A/D value.
- 5. After adjustment, move the tubular round arm L, and check that the hoop size matches the display on the test mode screen.